



# METAL PROTECT®

Ideal for all surfaces in satin or lucid steel, chromed, metals and varnished metals.

# METAL PROTECT®



## INNOVATIVE ANTIOXIDANT!

### Characteristics:

**Metal protect®** kit consists of two preparers and a protector; these will give the surfaces a look and performance never seen before.

The two preparers were studied to remove, in a more effective and faster way, filthiness of different natures allowing the surface to be ready for the final product.

## EASY TO APPLY!

In delicate surfaces (painted surfaces as example), it is always recommended to test in a hidden area to verify compatibility of the two preparers with the surface. If the two preparers are, "too aggressive" dilute the products with water (1:1 to 1:5 according to needs) or apply them to a wet surface and spray the product on a cloth instead of directly to the wanted surface.



### *How can you clean treated areas?*

A treated area must be cleaned with a clean and wet (with water) microfiber cloth or neutral cleaning products. Do not use alcohol or industrial solvents.

#### PRESENTATIONS:

- 1 liter
- 20 liters

#### PERFORMANCE:

- 130 - 150 m<sup>2</sup> per liter\*

\* Yield may vary depending on the substratum's properties.



UNIVERSITÀ DEGLI STUDI DI NAPOLI  
**FEDERICO II**



**Metal Protect® in addition to protecting you, it helps repealing dirt.**

## **THE PROCESS CONSISTS IN THREE STAGES:**

---

**Stage 1.** Apply preparer n1 pulverizing it in small areas (30x30cm) and using a microfiber cloth rub vigorously. Wash and rinse thoroughly with a clean sponge and dry it with a paper towel.

**Stage 2.** Clean thoroughly the microfiber cloth with tap water to neutralize the PH.

**Stage 3.** Apply preparer 2 following the same instructions above mentioned, wash rinse and leave the surface as dry as possible.

**Stage 4.** Surface must be perfectly clean, shiny and smooth in order to be protected. In case you observe oxide stains not perceived before we recommend you to use Inox & Piu in the identified area following the instructions on the label. When the oxide stains have been removed, please apply the two preparers again.

Apply now Metal Protect pulverizing it in small areas (30x30cm) and immediately extend the product with a paper or cotton towel (do not use the microfiber cloth) and polish the area clockwise in small and soft circles. Illuminated retro should not be observing halos. Cover all surface. If experimenting halos, polish the area with a wet cloth with Metal Protect treatment.

**Stage 5.** The optimum protection effect will be achieved 24 hours after the application.





**Diego Gonzalez**

Phone Number: 407-907-0972  
info@zamasolutions.com

[www.ZamnaSolutions.com](http://www.ZamnaSolutions.com)

